myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for SONY CYBER-SHOT DSC-S3000. You'll find the answers to all your questions on the SONY CYBER-SHOT DSC-S3000 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SONY CYBER-SHOT DSC-S3000
User guide SONY CYBER-SHOT DSC-S3000
Operating instructions SONY CYBER-SHOT DSC-S3000
Instructions for use SONY CYBER-SHOT DSC-S3000
Instruction manual SONY CYBER-SHOT DSC-S3000

SONY

4-273-931-**11**(1)

Digital Still Camera

Instruction Manual

Cyber-shot

DSC-S3000

Your user manual
SONY CYBER-SHOT DSC-S3000

Manual abstract:

For more detailed information about recycling of this product, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product. [Disposal of waste batteries (applicable in the European Union and other European countries with separate collection systems) This symbol on the battery or on the packaging indicates that the battery provided with this product shall not be treated as household waste. On certain batteries this symbol might be used in combination with a chemical symbol. The chemical symbols for mercury (Hg) or lead (Pb) are added if the battery contains more than 0.0005% mercury or 0.004% lead. By ensuring these batteries are disposed of correctly, you will help prevent potentially negative consequences for the environment and human health which could otherwise be caused by inappropriate waste handling of the battery. The recycling of the materials will help to conserve natural resources. In case of products that for safety, performance or data integrity reasons require a permanent connection with an incorporated battery, this battery should be replaced by qualified service staff only. To ensure that the battery will be treated properly, hand over the product at end-of-life to the applicable collection point for the recycling of electrical and electronic equipment.

For all other batteries, please view the section on how to remove the battery from the product safely. Hand the battery over to the applicable collection point for the recycling of waste batteries. For more detailed information about recycling of this product or battery, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product. GB 4 Refer to "Cyber-shot User Guide" (HTML) on supplied CD-ROM For details on advanced operations, please read "Cyber-shot User Guide" (HTML) on the CD-ROM (supplied) using a computer. Insert the CD-ROM into the CD-ROM drive.

For Windows users: 1 Click [User Guide] t [Install]. 2 Start "User Guide" from the shortcut on the desktop. For Macintosh users: 1 Select the [User Guide] and copy [eng] folder stored in the [User Guide] folder to your computer. 2 After copying is complete, double-click "index.html" in the [eng] folder. Checking the accessories supplied LR6 (size AA) alkaline batteries (2) Dedicated USB cable (Sony Corporation 1-837-597-) (1) Wrist strap (1) CD-ROM (1) Cyber-shot application software "Cyber-shot User Guide" · Instruction Manual (this manual) (1) · · · · GB 5 Identifying parts G Lens H LCD screen I (Playback) button J Control button Menu on: v/V/b/B/z Menu off: DISP/ / / K For shooting: W/T (Zoom) button For viewing: (Playback zoom) button/ (Index) button L Mode switch M Hook for wrist strap N (USB) / A/V OUT jack O (Delete) button P Access lamp Q MENU button R Tripod receptacle · Use a tripod with a screw less than 5.5 mm (7/32 inches) long. Otherwise, you cannot firmly secure the camera, and damage to the camera may occur. S T U V Speaker Battery/memory card cover Memory card slot Battery insertion slot GB A B C D E F 6 ON/OFF (Power) button Shutter button ON/OFF (Power) lamp Flash Microphone Self-timer lamp/Smile Shutter lamp Inserting the batteries/a memory card (sold separately) Ensure the notched corner faces correctly. 1 Open the cover. the memory 2 Insertthe notched cornercard (sold separately). memory card · With facing as illustrated, insert the until it clicks into place. 3 Match +/ and insert the batteries. 4 Close the cover. x Memory cards that you can use Memory Card Memory Stick PRO Duo A Memory Stick PRO-HG Duo Memory Stick Duo B SD memory card SDHC memory card For still images a a a a a For movies a a -- a a · In this manual, products in A are collectively referred to as "Memory Stick Duo" media.

· In this manual, products in B are collectively referred to as SD card. · When recording movies, it is recommended that you use Class 2 or faster SD cards. GB 7 x To remove the memory card/batteries Memory card: Push the memory card in once. Batteries: Be sure not to drop the batteries..

Your user manual
SONY CYBER-SHOT DSC-S3000